



Yak Digital Phone Features Quick Guide

FEATURE	DIAL	USAGE
<p>Call Screen (20 numbers max): The screened caller will not be able to access your voice mail and your Yak Digital Phone will not ring.</p>	* 60	<ul style="list-style-type: none"> • Call Screen is initially disabled <ul style="list-style-type: none"> ◦ To enable Call Screen press 1 • Once Call Screen is enabled your options are: <ul style="list-style-type: none"> ◦ To disable Call Screen press 1 ◦ To list Call Screen numbers press 2 ◦ To add a Call Screen number press 3 ◦ To delete a Call Screen number press 4 ◦ To add the last incoming call to your Call Screen press 5
<p>Call ID Block: The party called will not see your caller ID.</p>	* 67	<ul style="list-style-type: none"> • Enter a phone number followed by # after the tone <ul style="list-style-type: none"> ◦ The number entered will be dialled
<p>Call Return: View the last number that called you.</p>	* 69	<ul style="list-style-type: none"> • Press 1 to return the call
<p>Voicemail: Your default PIN is the last 4 digits of your Yak Digital Phone number. Remotely, dial your Yak Digital Phone number, press * when you hear your greeting and follow the prompts.</p> <p>PLEASE NOTE: PIN must be changed to access Voicemail remotely. You will be prompted to do so upon first Voicemail access. Voicemail messages will also be sent as an email with .wav file attachment.</p>	* 98	<ul style="list-style-type: none"> • Please enter your PIN followed by the pound key <ul style="list-style-type: none"> ◦ Press 1 to listen to new messages <ul style="list-style-type: none"> ◦ To repeat message press 1 ◦ To delete message press 7 ◦ To save message press 9 ◦ To play next message press 6 ◦ To play previous message press 4 ◦ Press 2 to listen to saved messages ◦ Press 3 for advanced options <ul style="list-style-type: none"> ◦ Press 1 to change your PIN ◦ Press 2 to record your name <ul style="list-style-type: none"> ◦ Press 1 to listen to the recording ◦ Press 4 to re-record ◦ Press * to go to the previous menu ◦ Press 3 to record a greeting <ul style="list-style-type: none"> ◦ Press 1 to listen to the current greeting ◦ Press 2 to record a new greeting <ul style="list-style-type: none"> ◦ Press 1 to listen to the recording ◦ Press 2 to save and set as an active greeting ◦ Press 4 to re-record ◦ Press * to go to the previous menu ◦ Press 4 to edit message review options <ul style="list-style-type: none"> ◦ Press 1 to change date review <ul style="list-style-type: none"> ◦ You will hear the current state/setting Press 1 to change the state (enable/disable) ◦ Press * to go to the preview menu ◦ Press 2 to change caller ID review <ul style="list-style-type: none"> ◦ You will hear the current state/setting Press 1 to change the state (enable/disable) ◦ Press * to go to the previous menu





Yak Digital Phone Features Quick Guide

FEATURE	DIAL	USAGE
Call Forward enable: Forward your calls to an alternative telephone number.	* 72	<ul style="list-style-type: none"> Enter the phone number you wish to forward your calls to, followed by the pound key after the tone.
Call Forward disable	* 73	<ul style="list-style-type: none"> To disable Call Forward
Follow Me: <i>Yak Digital Phone exclusive feature!</i> Enabling Follow Me means your Yak Digital Phone will ring first, if no answer, rather than go to your Voicemail, your calls will be routed to your chosen Follow Me numbers in sequential order (ex: mobile, cottage and work). Calls will then go to your Yak Digital Phone Voicemail if there is no answer at any of your Follow Me numbers. Up to 3 Follow Me numbers permitted.	* 88	<ul style="list-style-type: none"> Follow Me is initially disabled. <ul style="list-style-type: none"> To enable Follow Me press 1 Once Follow Me is enabled your options are: <ul style="list-style-type: none"> To disable Follow Me press 1 To list Follow Me numbers press 2 To add a Follow Me number press 3 To delete a Follow Me number press 4
Set number of rings	* 97	<ul style="list-style-type: none"> Select how long in seconds you would like your Yak Digital Phone to ring before your calls go to Voicemail The maximum length is 60 seconds and the minimum is 5 seconds
Do Not Disturb (DND): All calls go right to Voicemail when enabled.	* 99	<ul style="list-style-type: none"> DND is initially disabled Press 1 to enable <ul style="list-style-type: none"> Once DND is enabled, press 1 to disable DND
Speed dial menu	# 0	<ul style="list-style-type: none"> To add an entry press 1 <ul style="list-style-type: none"> Select a location between 1 and 9 to store this entry Enter a phone number followed by # after the tone To review your entries press 2 To delete an entry press 3
Speed dial	# 1-9	<ul style="list-style-type: none"> The number stored in the position selected will be dialled immediately If there is no number stored in the position selected you will be given an option to save a new number
Call waiting	N/A	<ul style="list-style-type: none"> Call waiting is a feature configurable on the device (ATA, IP Phone or X-Lite client)
Technical support	611	<ul style="list-style-type: none"> Call routed to Yak Technical Support
Emergency (nomadic)	911	<ul style="list-style-type: none"> Call routed to Operator

